

V-Twin Mfg.
JOCKEY PEDAL KIT, CHROME
 Fits 1986-99 ST Models
FOOTPEGS SOLD SEPARATELY
 VT No. 21-0114

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. Remove transmission side cover and remove old clutch cable and install the cable provided in kit.
2. Reinstall side cover and check/refill transmission fluid as needed.
3. Remove shifter rod assembly.
4. Remove bolt from shifter lever on transmission.
5. Install handle provided in kit onto the shifter lever and install bolt.
6. Support the motorcycle upright so that the kickstand can be removed.
7. Remove the shifter mounting plate.
8. Now install the clutch bracket then reinstall kickstand.
9. Hookup and adjust the clutch cable. Make sure cable is well lubricated.
10. Test ride by shifting through all gears.

Parts List:

VT No.	Description	Qty
21-0113	Jockey Pedal	1
36-0516	Clutch Cable	1
27-1519	Footpeg w/stud	1
21-0323	Jockey shift lever	1
21-0193	Jockey plate	1
13-9185	Spring washer	1
21-0117	Cable end busing	1
21-0313	Alloy spacer block	1
27-0030	Footpeg Mount	1

