



INSTALLATION

RUN-BRAKE LIGHTBAR FOR TOUR-PAK, 94-05 7757

PARTS INCLUDED

- 1 Tour Pak Light
- 1 Hardware Kit:
 - 1 Wiring Pig Tail
 - 3 Cord Keeper
 - 3 Male Scotch Locks
 - 3 Female Scotch Locks
 - 2 Dielectric Grease Packs
 - 4 4" Cable Ties
 - 2 Alcohol Pads
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Phillips Screw Driver, tape measure, side cutter

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

STEP 2 Remove the seat from the motorcycle and locate the main taillight harness as shown in PIC 1

Note: For bikes '96-up, following step 3 proceed to step 16 and continue installation.

Note: For '94-'95 models begin installation from step 4.

STEP 3 Disconnect the wiring harness; place a small amount of dielectric grease on the 8-pin connections from the main taillight wiring harness and plug the pigtail of the included wire adapter into the ends of the main taillight harness.

-cont.-

7757-11HD-1010

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.

• Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.

PROOF OF PURCHASE

kuryakyn.com



Note: If there is a run-turn-brake controller or panacea installed, the pigtail harness needs to be installed upstream (in front) of the controller.

ATTENTION! Kuryakyn recommends the use of dielectric grease on electrical connections.



Wiring Procedure for Models Previous to '96

STEP 4 Cut one of the three-pin pigtails from the included main pigtail harness as close to the connection point as possible (shown in PIC 2.)

STEP 5 Using wire strippers remove a small amount of insulation from the wire ends on the plug just removed from the included adapter.

STEP 6 Insert the exposed end of one wire into a male scotchlock and crimp the end making sure that the wire is secure, as shown in PIC 3

STEP 7 Repeat STEP 5-6 for the rest of the wires from the 3-pin pigtails.

STEP 8 On the bike, expose the main taillight wiring harness usually located under the seat.

STEP 9 Place a female T-Tap connector over the black (Ground), red (Brake) and blue (Run/Tail) wires in the main taillight wiring harness; close them, ensuring that the tabs are engaged as shown in PIC 4.



STEP 10 Place a small amount of dielectric grease on the male T-Tap connectors; insert the male spade connectors from the black wire into the female T-Tap connectors that was installed on the black wire on the taillight harness under the seat. Make sure the metal position of the spade terminal is fully inserted into the T-Tap clam shell.

STEP 11 Repeat STEP 10 for the red and blue wires, connecting the red wire to the red wire and the blue wire to the blue wire.

ATTENTION! Kuryakyn recommends the use of dielectric grease on electrical connections.


Light Installation

STEP 11 Clean the outlined area of the tour box. (Pic. 5)



ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50° F. Do not attempt this installation in temperatures less than 50°F.



STEP 13 With a tape measure, find the center of the tour box (Pic. 5). Using a piece of masking tape make a non-permanent mark that will help you locate center.

STEP 14 Test fit the light to the tour pak, notice how the light fits with the curve of the tour box. Make any small non-permanent mark that will help you line the light up when fully installing to the tour pak. Double check your location before permanently installing.

STEP 15 With the back of your fingernail, rub the adhesive backing on the backside of the light.

STEP 16 Remove backing and apply the light to the tour pak lining up any mark previously made in step 14. Press and hold for one full minute, full bonding will occur in 24 hours.

STEP 17 Take the wire and route it along the bottom of the tour pak.

STEP 18 Use the provided cord keepers and space them evenly on the bottom of the tour pak to secure the wiring from any possible pinch points and or moving parts. Clean the areas before applying the cord keeps.

STEP 19 Connect the light plug to the pigtail end.

STEP 20 Turn the ignition on and test to make sure that the lights function as both running lights and brake lights. If they do not function, go over all wiring connections.

STEP 21 Replace the seat. After all wires have been secured, make sure no wires or connectors are pinched.

ATTENTION! Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.